

ONE

Quick Start Guide

EN

Congratulations on your new Olive ONE, the world's first Music Player actively developed by its user community.

1

Before you start

What's in the box

- Your ONE comes with the following accessories:
- This Quick Start Guide
- 3.5mm-to-RCA audio cable (analog)
- Power Cord

Before setting up your ONE

- Make sure the ONE and any devices you will connect it to are powered off.
- Set the volume control on your amplifier to zero.


A DO NOT connect headphones to the ONE's ANALOG OUT connector. Headphones have different impedance and can damage the ONE's digital-to-analog converter.

2

Connecting the ONE

To your amplifier or receiver

- Use the supplied 3.5mm-to-RCA cable to connect the ANALOG OUT connector of the ONE to the appropriate RCA inputs on your amplifier.
- OR, use a digital coax cable to connect the DIGITAL OUT connector of the One to the appropriate digital input on your amplifier. (To play music via digital out please go to PREFERENCES > AUDIO and turn on DIGITAL).



To your unpowered (passive) speakers


Connect passive speakers directly to the SPEAKER OUTPUTS. You can use speaker cables that are unterminated, or with standard banana plugs.

A The amplifier has an output of 2x 32W, so we recommend speakers that have at least 40W RMS.

3

Powering up your ONE

Tap on the POWER/SLEEP button, and the touch-screen of your ONE will light up. The boot up process can take up to 40 seconds, depending on the size of your music library.



- i** To put the ONE to sleep tap the power button quickly.
- If your ONE is non-responsive for an extended period keep your finger on the power button for ~10 seconds and the ONE will reboot. Remember to turn down the volume on your amplifier/receiver to zero before rebooting your ONE.

4

Connecting to your network

To access the network setup menu please tap on the SETTINGS icon and select CONNECTIVITY. Choose one of the following options:

- WIFI: Turn ON WiFi and select your network. Enter the password and the ONE will connect automatically to your network.
- ETHERNET: Connect your ONE via wired connection to your router.

i Tap on the icon for a manual network setup.

If your wireless network does not show up in the list we recommend attaching an external antenna (with a female RPSMA connector) to the WiFi connector on the backside of your ONE:



Once you have setup your ONE we recommend that you install the latest software by following the menu sequence SETTINGS > SYSTEM > UPDATE/RECOVERY.

5

Transferring music to the internal HDD

If your ONE has a built-in hard disk drive, you can transfer the music from your Mac or PC to the ONE:

1. Tap on the network status icon in the top left corner of the ONE home screen and write down the IP address assigned to the ONE.
2. **On a PC** press the WINDOWS + R keys on your keyboard.
On a Mac choose GO > CONNECT TO SERVER (from the main menu on your desktop).
3. **On a PC** enter "\\IP Address" and click OK.
On a Mac enter "smb://IP Address" and click OK. Connect as a "Guest".


An import folder named "Olive Music" will appear on your desktop / network environment. Drag and drop your complete music folder into the import folder. A pop-up on your desktop will indicate the estimated time for the transfer. The ONE will start importing the transferred music automatically into its local database. Once the import is complete your music will appear in the ONE's local music library.

- i** We recommend using a wired Ethernet connection to transfer larger music libraries.
- Only supported audio formats (WAV, AIFF, FLAC, MP3, AAC, Apple Lossless, Ogg Vorbis) will be imported.
- Music in WAV/AIFF format does not have metadata tags and will show up as Unknown Artist/Album in the ONE's music library.
- For instructions on how to install your own hard disk drive please go to <https://olivemediainc.zendesk.com>

6

Navigating the ONE touch-screen

You can access all key features from the home screen and launch bar.



- One tap selects item
- Double-tap starts playback
- Keep finger pressed on item to open pop-up with additional functions (delete, add to playlist etc.)

* Network connection status: White network icon confirms Internet access. Red icon indicates no Internet. Crossed-through icon means no network access.

7

Playing music from your smartphone/tablet

1. Select SOURCES from the ONE home screen and click on the Bluetooth icon.
2. Turn ON Bluetooth and wait until the status messages changes to "Initialized".
3. Turn ON Bluetooth on your portable device and select the ONE in the device list.
4. Once the status on the ONE changes to "Connected" start the music playback from your phone. The ONE will automatically change to the play-screen.

Playlist and additional information

For more information about how to create playlists, setting up an alarm or other settings please visit us at <https://olivemediainc.zendesk.com>

Take part in developing ONE!

The ONE project was born through a crowd-funding campaign, and its development has been driven by its funders and supporters ever since. It is the world's only music player that allows you to actively participate in the development of new features and design. Let us know what features you would like us to add to your ONE: <https://olivemediainc.zendesk.com>

Questions and Feedback

If you are experiencing technical problems with your Olive ONE please contact us through <https://olivemediainc.zendesk.com>. We pride ourselves to respond to all inquiries within 24 hours during business days (Monday through Friday, 8am to 5pm PST).

Notices - Regulatory

FCC Compliance Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected; Consult the dealer or an experienced audio technician for help. Modifications not expressly approved by the manufacturer may void the user's authority to operate the equipment under FCC rules.

Canadian Compliance Statement This Class B digital apparatus complies with Canadian ICES-003 and RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Industry Canada: The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site www.hc-sc.gc.ca.

EU Compliance Statement Olive hereby declares that this product complies with the requirements and other relevant provisions of the R&TTE Directive. A copy of the full Declaration of Conformance may be obtained at www.myoliveone.com/compliance. In France, operation is limited to indoor use within the band 2.454-2.4835 GHz. (Attention. En France, l'utilisation en intérieur est limitée à la bande de fréquences 2,454-2,4835 GHz.)

RF EXPOSURE REQUIREMENTS To comply with FCC and EU exposure essential requirements, a minimum separation distance of 20cm (8 inches) is required between the equipment and the body of the user or nearby persons.

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead please deliver it to the applicable collection point for the recycling of electrical and electronic equipment. By recycling this product correctly, you will help conserve natural resources and prevent potential negative environmental consequences. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the store where you purchased the product.



Olive and Olive ONE are trademarks and/or registered trademarks of Olive Media Inc. in the United States and/or other countries. Information is subject to change without notice. © 2014 Olive Media Inc. All rights reserved.